




# Installation of Capacitor Expulsion Fuse


## << For Edge Mount Capacitor >>



## << For Upright Capacitor >>



## << For Three Phase Capacitor >>



Unit: mm



裕昌機電工廠股份有限公司  
YUHCHANG ELECTRIC CO., LTD.